

1. First things first - let's make sure you have everything you'll need to perform a good installation. Below is a list of the hardware included in your kit and a list of the tools you should have for use:

**Hardware Included:**

- Rear Spoiler
- Brake Light (if applicable)
- Gaskets
- M6 X 16mm Steel Screws
- Drill Locator Strips
- Rubber Hole Plugs (if applicable)

**Tools Required:**

- Drill
- 1/8" Drill Bit
- 5/16" Drill Bit
- Hex Head or Phillips Screwdriver
- Masking Tape
- Rust Proof Paint

2. Next prepare and clean the trunk lid for working. Make sure the surface is free of dirt and is dry.

*Note: Always pre-fit the spoiler to the vehicle to make sure that it is the proper model for the application before painting, drilling, or cutting. Improper installation will void your warranty. Parts, which have been painted, modified or prepped, can't be returned.*

3. Now locate the plastic drill locator strips from the included hardware kit. Insert them into the mounting holes on the spoiler as seen in the picture below. Use masking tape to hold the strips in place if necessary.



4. Carefully position the spoiler and find the most suitable location. You can use measurements to make sure it's even. Once you have the spoiler where you want it, tape the locator strips to the trunk lid.



5. Remove the spoiler leaving the locator Strips taped to the trunk; drill holes in the centers of the strips which are easily located by the little nubs that were previously in the mounting holes of the spoiler. Use the 1/8" Drill Bit.



6. After drilling the 1/8" holes remove the locator strips and use the 5/16" bit to widen the holes. If your spoiler has a light, you will have to find the point directly between the two holes you've drilled for the side of the spoiler containing the wire for the light. Once this point is located drill a hole through it using the 1/8" bit; then the 5/16" to widen (a universal drill bit makes this task easy).

7. Treat all bare steel with rust proof paint.

8. Open your trunk; if you have plastic or rubber plugs already in the location underneath the holes you've drilled to mount the spoiler, remove them and proceed to step 10.



If there are no plugs or holes already in place on the underside of the trunk, you will have to make use of your hex head or phillips screwdriver and rubber mallet for this next step (you can use your hands if you don't have a rubber mallet). Perform the following steps for each mounting hole you drilled in the previous steps:

a. Put the screwdriver through one of the top mounting holes.



b. Holding the screwdriver firmly in one hand, strike the handle with your hand or rubber mallet with enough force to make a good indentation on the underside of

the trunk. You're not trying to poke it through, just make an indentation.



9. You will have to match the diameter of the provided plugs (also known as grommets or rubber hole plugs) with a drill bit; if using a universal drill bit this will be easy. Most grommets will require a 5/8" diameter or slightly larger. Center the bit on the indentations you made in the previous step and drill out all necessary holes.



10. If your spoiler has a light and you've drilled the hole for the wire, now is the time to run the wire through the hole and proceed to the next step. Make sure that if you have a gasket to put in between the spoiler and the trunk lid, you should put the wire through the gasket as well. If your spoiler doesn't have a light, proceed to the next step.

11. Place the gasket in proper place if not already attached to the spoiler and screw the spoiler in by using the holes drilled underneath the trunk lid to put your screw through to the appropriate hole in the spoiler.



12. If you have not yet connected the wire for the spoiler light to the appropriate brake light (normally whichever is closest) do so now.

13. Plug the holes on the underside of the trunk lid from step 9 with the provided plugs (you'll put back the plugs that were previously over the holes if you didn't need to perform step 9). Clean off any metal shavings from your trunk

14. Show off your new spoiler to all your friends (you might even be able to make some nice side money doing it for others now that you're a pro)!